




Changing the user code.

Set the valid user code. Press the programming pin into the knob (for example with the code tool or a ball-point pen) and, with the programming pin held down, rotate the knob by approx 20° until the arrow at the base of the knob is aligned with the red triangle on the lock case. A slight resistance can be felt. The code tool is no longer required.

Set your personal code and make a note.

Turn the knob back to closed position. Programming pin returns back to the initial position. Open and close the lock. Code is scrambled.

Lock is closed and the new personal code is saved.

Modification du code utilisateur.

Définir le code utilisateur. Appuyer sur le pin de décodage et pousser vers le bas (avec l'aiguille prévue à cet effet ou un stylo) et le maintenir pour faire tourner le bouton d'environ 20° jusqu'à ce que la flèche soit positionnée au centre du triangle rouge. Une petite résistance se fait ressentir. L'aiguille peut alors être retirée car elle se sert plus.

Régler et noter votre code personnel.

Tourner le bouton pour le repositionner en mode verrouillage – le système revient en position initiale. Ouvrir et fermer la serrure : Le code est effacé.

La serrure est fermée et le code nouveau est sauvegardé.